

Immersion Heater and Tank Compatibility Chart

Immersion Heater & Tank Compatibility Chart		Adveco SSB, SSI, SST								Adveco SSB Electric							
		200	300	500	800	1000	1500	2000	2500	200	300	500	800	1000	1500	2000	2500
3kW	E0021	✓	✓	X	X	X	X	X	X	✓ 1-3	✓ 1-3	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4
	EB0014	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0014A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
6kW	E0022	✓	✓	X	X	X	X	X	X	✓ 1-3	✓ 1-3	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4
	EB0015	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0015A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
9kW	E0023	✓	✓	X	X	X	X	X	X	✓ 1-3	✓ 1-3	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4
	EB0016	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0016/1PH	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0016A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
12kW	EB0016A/1PH	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	E0024	X	X	X	X	X	X	X	X	X	✓ 1-2	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4	✓ 1-4
	EB0017	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0017A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
18kW	EB0018	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
	EB0018A	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
24kW	EB0019	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	EB0019A	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
36kW	EB0021	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
	EB0021A	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
18+9kW Two-stage	EB0027	X	X	✓	✓	✓	✓	✓	✓	X	X	✓	✓	✓	✓	✓	✓
21+21kW Two-stage	EB0031	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X

Key: X Incompatible combination

✓ Can optionally mount one of these in the side/cleanout port

✓ 1-# SSB Electric Primary ports - can mount multiple of the ticked *E00##* elements

